

INSTALLATION INSTRUCTIONS IMPRESSIONS ACOUSTICAL FABRIC

MAINTENANCE AND CLEANING

IMPRESSIONS High-Performance Acoustical Wallcarpet, made with face fibers of Polyester and specially formulated for enhanced pill resistance, will stay attractive and serviceable with regular vacuuming. Most spots and stains will disappear when treated with mild detergent or cleaning solvent. Treated with a special fluorocarbon treatment that provides stain and soil repellency as well as greatly increased cleanability. It dramatically cuts on-site maintenance and replacement costs, adds years to the life of the fabric, and makes every installation a better investment.

MATERIAL

Carefully inspect all shipments. Check and examine material. We cannot be responsible for any imperfections after goods are cut.

Before cutting, be sure the pattern and color are satisfactory. Contractor assumes all responsibility for goods after cutting. No claims will be allowed for labor. All returns must have prior Return Authorization Number and are subject to a 30% restocking charge. All requests for returns must be made within thirty (30) days of ship date.

WALLS

Walls are to be structurally sound and free of dirt, grease, and markings. All markings that cannot easily be removed should be sealed so that "bleeding" through the wallcovering shall not occur. Although it is not necessary for the installation of wallcarpet, sealed walls, especially on newly installed drywall, could facilitate future removal of wallcovering and lessen damage to walls. Prime new drywall / painted surfaces with Gardner-Gibson Dynamite #222, or equivalent.

INSTALLATION

Cut material to desired lengths, allowing for top and bottom trimming. Apply Gardner-Gibson Dynamite #433 (or equivalent) heavy-duty clay strippable adhesive, full strength, directly to the wall and allow to dry overnight. (IMPORTANT!!! ADHESIVE IS READY MIXED AND SHOULD BE USED AS IT COMES OUT OF THE CAN. DO NOT MIX WITH WATER AND DO NOT PASTE THE BACK OF THE WALLCOVERING).

WALLCARPET SHOULD BE HUNG STRAIGHT UP...DO NOT ALTERNATELY REVERSE STRIPS. Dry hang material with another application of Dynamite #433 (or equivalent), allowing it to dry to its maximum tackability without it being overly dry. This material is not factory trimmed. All edges must be butt joined. Be careful not to get adhesive onto the face of the wallcovering, as it cannot readily be removed. Should adhesive get onto the face, it is best to allow it to dry and flake it off with a stiff brush. Do not attempt to wash affected areas, as this will only serve to dilute the adhesive and spread it over a wider area.

Install three strips and inspect all for color, uniformity, and correctness of application. If satisfactory, proceed with work. As work proceeds, small areas (3 strips) should be inspected so that there are no more than 3 strips in question at any time. If anything goes wrong, STOP WORK IMMEDIATELY and contact WALL RESOURCES for inspection.

All seams shall be at least 6 inches away from inside or outside corners. Headers over doors may cause shading.

COVERAGE:

Primer- Gardner-Gibson Dynamite #222	400-500 square feet per gallon
Adhesive- Gardner-Gibson Dynamite #433	100 square feet per gallon, per coat

Material Width: Available in both 74/72' (18 sq.ft. / lin.yard) and 110/108" (27 sq.ft. / lin.yard)

This application provides a strippable system for removal and repair purposes. For best results, it is recommended that a qualified textile installer be employed.